



INSTALL ADHESIVE FRICTION BRUSH




WEATHER-STRIPPING

INSTALL ADHESIVE FRICTION BRUSH



A

INSTALL ADHESIVE FRICTION BRUSH



FIXED PANEL

WEATHER-STRIPPING TO OUTSIDE

WEATHER-STRIPPING TO OUTSIDE

WEATHER-STRIPPING TO OUTSIDE

WEATHER-STRIPPING TO OUTSIDE

B

A5

A2

B3

A5

A2

B3

A2

A2

I TYPICAL FIXED PANEL ASSEMBLY I

INSTALL ADHESIVE FRICTION BRUSH

